



EG-C-308 Installation Instructions

Markar Architectural Products, Inc. a subsidiary of Adams Rite Manufacturing Co.
260 Santa Fe Street, Pomona, CA 91767

Phone: 800-872-3267 Fax: 800-232-6752

www.markar.com

Failure to use the fasteners supplied by Markar Architectural Products Inc. will void the UL fire rated listing.

- (1) Place the edge guard over the edge of the door as shown in Figure 1 on the back of this page.
- (2) With the edge guard lined up evenly with the top of the door (of the hardware cut out), mark the position of the holes using a center punch. The use of the Markar MT-806 center punch can help center the hole so that the fasteners will enter straight. The taper on the tool sits in the countersunk hole on the hinge.
- (3) Remove the edge guard and prep each hole location by pre-drilling with a #25 bit.
- (4) Position your edge guard back up and align with pre-drilled holes in door.
- (5) Finish installation by drilling and fastening your edge guard using sheet metal screws supplied.